Data Module Code: SPARTAN-AAA-00-00-00A-0000-A

Issue Number: 000 In Work Number: 00

Issue Date: 08-March-2025

SPARTAN-ST

Storage Instructions

Security Classification: NO SECURITY RESTRICTIONS

Quality Assurance Status: First verification performed with drawings and on the compo-

nent.

Applicable to: SPARTAN-ST

Table Of Contents 1. Storage Instructions 3 2. Battery Storage Guidelines 3

References No References

1. Storage Instructions

The following should be ensured for the storage of the goods:

- 1. Ensure the sight is cleaned as per cleaning instructions received in the maintenance manual.
- **2.** Ensure the sight does not have any battery inside.
- **3.** Store and transport the unit only in its hard case.
- **4.** For extended storage, wipe the device housing, clean the optical surfaces and store in the rugged case supplied.
- 5. Although the equipment is tested to withstand storage temperatures and humidity conditions as per JSS 5855-11-2019, for prolonged life of the equipment we recommend you do not store it in extreme temperatures for long periods. The ideal recommended temperature for extended storage is 20 degrees and 40% RH in a controlled environment or in a storage chamber, if available

2. Battery Storage Guidelines

A. Charging Levels

It is essential to store the battery with approximately 30% charge to optimize longevity and performance.

B. Charge Monitoring

Check the battery charge level during periodic maintenance to ensure the battery does not deplete below the optimal 30%. Recharge if necessary.

Applicable to: SPARTAN-ST SPARTAN-AAA-00-00-00A-0000-A